

Lakewood Ridge Townhomes

Architectural Standard for Water Softeners

No taller than the window sill and must be surrounded by bushes and completely hidden.